

## Notice

Do not push strongly on the External I/O with the pointed object.  
The External I/O may get stuck into the unit, and you may not be able to use it.

